

Teemi

USB Barcode

Program Chart

FSI—Ross Snyder—August 9, 2021

1



0D0100.

Restore All Factory Defaults

2



0606001.

USB Cable

3



060E000.

1 – U.S. (Default)

4



05021D1.

Low

5



0502161.

Short

6



090201.

Add TAB

7



0211020.

Disable UPC-A Check Digit

8



0212040.

Disable UPC-E0 Check Digit